

kookaburra

Tent Fan with LED Light

Assembly & Care Instructions



IMPORTANT

Read these instructions
for use carefully.

Keep these instructions
for future reference.

DO NOT stare directly
at the LED light when
switched on.

Not intended for
use by children



Assembly & Care Instructions

PARTS LIST

- 1 Hanging Hook
- 2 Battery Cover
- 3 Batteries (not included)
- 4 Fan Switch (High/off/low)
- 5 Light Switch (Off/On)
- 6 Fan Housing
- 7 Light Housing



TO INSTALL OR REPLACE BATTERIES:

- Use alkaline batteries to operate this product
- Do not mix old and new, rechargeable or other batteries
- Ensure the product is switched off before installing or replacing batteries
- Place tent fan so battery cover is facing up
- Unscrew cover and open battery compartment
- To open battery cover, turn anti-clockwise
- Install batteries as indicated inside battery compartment
- To close battery cover, turn clockwise
- Always ensure that battery compartment and cover are securely closed before operating, transporting or mounting the tent fan



TO MOUNT TENT FAN IN A TENT:

- Hang tent fan by hook to a secure structure inside the tent (eg pole)
- Tent light adjustable 180°
- Ensure that the secure structure inside the tent can withstand weight of the tent fan



WARNING:

- **Do not** stare directly at the LED lights when switched on
- Run times for fan and lights depend on condition of batteries used and conditions under which product is used
- Never use a mix of batteries of different brand or type
- **Do not** leave batteries inside tent fan for an extended period of time as batteries could leak and permanently damage the product
- To clean outside of tent fan, use only a damp cloth and mild dish washing detergent
- Avoid using excessive water and strong cleaners that may damage the product
- **Not to** be exposed to rain



SPECIFICATIONS

Weight	724g (with batteries)
Batteries	2 x D cell (not included)
Fan Run Time	Up to 50 hours* (on low speed) Up to 30 hours* (on high speed)
Light Run Time	Up to 37 hours*

* Fan and light run times are dependent on battery and weather conditions



Distributed by
Primus Australia Pty Ltd.
Bundoora VIC 3083.
www.primusaustralia.com.au